


Materials/Supplies/Tools Needed

- Printer
- Cardstock (a.k.a. thick business card paper)
- Craft/utility blade (a.k.a. X-Acto)
- Multi-Purpose Paper Glue (a.k.a. Elmer's Glue-All)

Assembly Instructions



On the *Cutting Instructions* page the layers are labelled with numbers so as to denote their relationship to this diagram. The topmost layer is 1 and the bottom layer is 5. The second layer has two parts a and b. Apply glue to **BOTH** sides of pieces **2.a** and **4**. Any images/text should always point upwards. As a word of warning be careful with how your printer deals with cardstock. It may not be built to handle paper of such thickness.

- Press layers 1, 2.a, 2.b and 3 together (after having applied glue to layer 2.a).
- Fold the triangular tips of level 2.b outward.
- Press the three topmost layers and level 4 and 5 together (after having applied glue to layer 4).
- Be sure to rotate level 2.b ("gear") to ensure it does not adhere to any other parts of the device.

Cutting Instructions

This page is provided as a template to guide you on how to cut the Level Counter pieces from the paper.

CUT along all red lines.

SCORE along all blue lines.

Repeat that procedure for every subsequent piece you print out.

